


INSTRUCTION MANUAL



COMMUNICATOR HEADSET


For use with For XBOX 360™

Introduction

Congratulations on your purchase of Datel's Communicator Headset for Xbox 360™. Now you can take charge in Xbox 360™ games with talk or voice control features.

Connecting and using your Communicator Headset

360 controller



↑
Headset

1. Turn the volume wheel all the way to the left on the headset adapter to reduce the volume to its minimum. Connect the adapter to the expansion port at the bottom of your Xbox 360™ game controller.
2. Connect the 2.5 headphone jack plug of the Communicator Headset into the socket on the bottom of the headset adapter.
3. Fit the Communicator Headset over your ear and align the microphone.

Note

Correct placement of your headset and microphone is important to using your headset successfully in your games. With the earpiece looped over your ear, angle the mouthpiece towards your mouth. The mouthpiece is designed to point the microphone towards your mouth without actually being directly in front of it. This is to ensure good pick up of your voice without picking up your breathing.

4. You are now ready to start your game or chat session. Start your game or chat and set the volume to a comfortable level using the volume wheel on the headset adapter.



Hearing Loss

Prolonged exposure to loud volumes may result in temporary or permanent damage to your hearing. Be careful to not set the volume level too high on your headset and take regular breaks when gaming or chatting.

For information about using your headset with a specific game, see your game's manual.

Troubleshooting

You can't hear anything

Check that:

- The volume isn't turned right down.
- The headset jack plug is pushed in all the way into the Universal Headset Adapter.
- The adapter is properly connected to the controller.

Others can't hear you

Check that:

- You do not have the mute button in the left (muted) position.
- The headset jack plug is pushed in all the way into the Universal Headset Adapter and that the adapter is properly connected to the controller.
- Voice isn't muted in Xbox Guide.
- You don't need to press a button to speak in your game manual.

Technical Support

Before contacting Datel's customer service department, please ensure that you have read through and understood the information in this manual.

Please ensure that you have information on when and where you purchased this product to hand.

DATEL CUSTOMER SERVICES EUROPE:

Customers Services,
Datel Ltd,
Stafford Road,
Stone,
STAFFS
ST15 0DG
UNITED KINGDOM

Email: support@datel.co.uk
Web: www.codejunkies.com

DATEL CUSTOMER SERVICES USA:

ATTN: Customer Services,
Datel Design & Development Inc,
33 North Garden Avenue,
Suite 900, Clearwater, FL 33755

Email: support@datel.design.com
Customer service knowledgebase: www.datelcustomerservice.com
Main website: www.codejunkies.com

© 2006 Datel Design & Development Ltd. Communicator Headset is a trademark of Datel Design and Development Ltd.

Communicator Headset for Xbox 360™ is a 100% unofficial product and is NOT sponsored, endorsed or approved by Microsoft Corporation, nor any games developer or publisher.

Microsoft, Xbox, Xbox 360 and Xbox Live are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.